

**Heater Accessories Part Numbers / Description**

## HEATER ACCESSORIES

12-2114	Vacuum - Solenoid - 12 Volt
12-2115	Vacuum - Solenoid - Cap (3 Port)
14-2383	Manual Shut-off Valve 5/8" x 5/8"
14-2384	Inline valve 5/8" normally closed
14-2395	Electric valve 12 volt

## WATER VALVES

14-2350	Normally Open - Closes By Vacuum 5/8" x 5/8"
14-2351	Normally Closed - Opens By Vacuum 5/8" x 5/8"
14-2356	Normally Open - Closes By Vacuum 5/8" x 5/8"
14-2387	Normally Closed - Pull To Open 5/8" x 5/8"
14-2389	Normally Positive Close Pull To Open 5/8" x 5/8"
15-2401	Vacuum pump 12v DC
15-2402	Booster water pump